

This diagnostic software can test Chrysler ECUs, including: Engine, Automatic Transmission, Anti-lock Brake, Airbag, Body, A/C, Dashboard, Memory Seat, Trap-door, Steering Angle, Wireless Control Module, Tire Pressure, etc.

Model Coverage:

300M	300	ASPEN
CIRRUS	CONCORDE	PACIFICA
PT CRUISER	SEBRING	LIBERTY
AVENGER	CALIBER	COMPASS
CHALLENGER	CHARGER	DAKOTA
DURANGO	INTREPID	JOURNEY
MAGNUM	NEON	NITRO
RAM 1500	RAM 2500	RAM 3500
STEALTH	STRATUS	VIPER
CHEROKEE	GRAND CHEROKEE	
GRAND CARAVAN		CARAVAN
TOWN&COUNTRY		COMMANDER
GRAND VOYAGER		VOYAGER
PATRIOT	WRANGLER	

Basic Functions:

- Read car computer information
- Read car fault information
- Clear car fault information
- Read car running data
- Actuation test for car component

Special Functions:

- ※ ENGINE [Engine System]:
 - Check PCM Odometer
 - Check PCM VIN
 - Learn ETC
 - Reset ECU
 - Reset Memory
 - Clear Variable Line Pressure(VLP) Counters

- Relearn Cam/Crank
- Injector Quantity Adjustment
- View/Reset duty cycle accumulators
- View/reset trip information accumulators
- Enable / Disable vehicle features
- Reset Nox adsorber counts
- Reset after treatment trip information
- Turbo actuator pre-align / self calibrate
- Reset regenerative filter timers
- Reset Fuel Pressure Limiting Valve Accumulators
- Stationary Desoot
- View/Reset Duty Cycle Maps
- Idle Shutdown Timer Adjustment
- Oil Change Monitor Type
- View/Reset NAC After Treatment Over Temp Events
- Manual DPF Regeneration
- DPF Replacement
- ECM Replacement

※ TCM [Transmission Control Module]:

- TCC Break-In
- Initialize CVT
- Initialize EGS-52/53
- TCM Store Adaptive
- Reset ECU
- Reset Learned Adaptives
- Store Learned Adaptives

※ ABS [Antilock brake controller]:

- Bleed Brakes
- Reset ECU

※ ORC [Occupant Restraint Controller]:

- Reset ECU
- Initialize ORC
- Rollover Detection

※ BCM [Body Computer Module]:

- Reset ECU
- Illuminated Entry Time
- Flash Hazard Lamps On Lock
- Accessory Delay Time
- Enable DRL
- Temporary Tip Start Disable
- Enable Front Fog Lamp Output
- Disable Radio Clock Display
- Change Country Code
- Program Network Configuration
- Program Tire Size
- Change Measurement unit
- Language preference

※ WCM [Wireless Control Module]:

- Reset ECU
- Program Left Rear Tire Sensor ID
- Program Left Front Tire Sensor ID
- Program Spare Tire Sensor ID
- Program Right Rear Tire Sensor ID
- Program Right Front Tire Sensor ID
- TPM Trigger Module Test